



Excavators - Controls Instructions

The operator must read these instructions before starting the excavator.



Un-programmed key



Insert key

Beep! Beep!



The alarm sounds

Programmed key



Insert key

Vroom...



The excavator moves

